


MelcoBEMS A1M - Updating XML File

The XML file can be located in the below location.

C:\Program Files (x86)\Mitsubishi Electric\MelcoBEMS MINI (A1M)\Config Manager



Delete the existing XML file and replace with the updated version.

